



Positioning of Magnetic Sensors/Permanent Magnets — OSP-E..BHD

Standard Version




Drive Shaft Option = 0




Drive Shaft Option = 1

Bi-Parting Version




Drive Shaft Option = 2




Drive Shaft Option = 3

When arranging the magnetic switches, please mind the position of the magnets integrated in the carrier as a function of the operating direction.  
“M” indicates where magnet is fitted in carrier.

Dimensions for magnetic switch set  
Series OSP-E..BV



The magnetic switch as well as the magnet can be fitted to either side



Dimensions see page 146

Magnetic switch and magnet are externally fitted to the OSP-E..BV.

For this purpose please order the magnetic switch set (consisting of 2 magnetic switches, 1 fastening rail and 2 magnets) for contactless position sensing.